



Procedure for Washing Spun Bond Polyester Filter Cartridges

1. Pulse off line for approximately 30 minutes.
2. Remove filter from system and inspect for damage. Do not re-use damaged cartridges with bad gaskets, dented end caps, screens or torn media.
3. Vacuum or gently shake the cartridge to remove excess dust.
4. Using Compressed air (70 PSI maximum) blow from the inside out to prevent blinding the media.
5. Use a standard garden hose (40 PSI maximum) and clean the cartridge inside and out until clean.
6. Blow excess water off using compressed air (40-50 PSI maximum) both inside and out.
7. Dry filters for a minimum of 72 hrs before returning to system use.
8. Protect cartridge from dirt and/or contaminants during the drying process.